## WBNG GAS PLUMBER METER PROCEDURES

At the time of a request for service/sign-up, WBNG will provide the customer a copy of our meter procedures, including a Yellow Inspection Tag & information on the Customer Valve below. Customer or Customer's gas plumber must coordinate Gas Meter location with WBNG.

## WBNG DOES NOT ACCEPT TRACPIPE OR ANY TYPE OF FLEXPIPE





Location of house piping stub out must be coordinated with WBNG to ensure safety and proximity to an electrical meter for meter reading. If the meter location is different from the piping stub out, the gas plumber will be responsible for piping to the final meter location. House piping should be within 2 FT of the meter location to the Customer Valve on the outlet side of WBNG'S meter assembly.





AFTER



The **Yellow Flag** will normally be to the left of a stub out as pictured here unless septic lines or other underground lines or equipment interfere with the location of the gas meter.





WBNG will run its service line, set its meter and then lock the meter assembly.

The plumber is responsible for connecting the house piping to the Customer Valve on the outlet side of WBNG's meter assembly.

## FOR A METER TURN ON:

- 1. "INSIDE" a municipal jurisdiction requires the building inspector's release/approval form.
- 2. "OUTSIDE" a municipal jurisdiction requires a completed Yellow Inspection Tag.

## REMEMBER: Pressure gauge must set 15 psi for 15 minutes!

WBNG will then unlock its meter assembly and turn on the gas to the customer valve. The Plumber will then remove his gauge, insert a plug, turn on the Customer Valve and soap the plug before purging the house piping and lighting appliances.

In order to prevent any additional trip charges, DO NOT REQUEST WBNG INSPECTION UNTIL YELLOW TAG IS COMPLETED AND ATTACHED TO PIPING. An additional \$50.00 will be charged for subsequent inspections.

WBNG DOES NOT ACCEPT TRACPIPE OR ANY TYPE OF FLEXPIPE

Customer or Customer's gas plumber must coordinate Gas Meter location with WBNG.

